



**NOTES:**

**1. OPERATION**

1. GENTLY LIFT LATCH AT SIDE OF CONNECTOR.
2. SWING COVER OFF OF CONTACTS.
3. SLIDE THE FLEX TAPE INTO THE CONNECTOR PLACING THE EDGE OF THE FLEX TAPE UNDER 2 HOLD DOWN TABS. MAKE SURE THE POLARITY IS MATCHED BETWEEN THE FLEX TAPE AND THE CONNECTOR COVER.
4. FOLD OVER THE COVER AND PRESS IN PLACE UNTIL THE LATCH IS FULLY ENGAGED.

2. LIMIT CURRENT TO A MAXIMUM OF 5 AMPS.

3. WILL WORK WITH 10mm OR 12mm WIDE FLEX RIBBON.

**JKL PART NO.: ZFS-CH144-12I**

		<p>THIRD ANGLE PROJECTION</p>		<p><b>METRIC</b></p> <p>DIMENSIONS ARE IN mm (INCHES)</p> <p>TOLERANCE UNLESS OTHERWISE SPECIFIED</p> <p>1 PL +/- REF.</p> <p>2 PL +/- REF.</p> <p>ANGLE +/-</p>		<p><b>JKL COMPONENTS CORPORATION</b></p>									
<p><b>A</b> ADD NOTE 3</p>		<p>10/8/13</p>		<p>DRAWN BY L. WENGSTROM</p>		<p>APPV'D BY L.R.</p>		<p>DATE 10/8/13</p>		<p>SIZE <b>A</b></p>		<p>FSCM NO. <b>55335</b></p>		<p>DRAWING NO. <b>ZFS-CH144-12I</b></p>	
<p>RELEASE &amp; CANCEL PL-1206-02</p>		<p>3/5/13</p>		<p><b>- CAD DRAWING -</b></p> <p>MANUAL REVISIONS NOT PERMITTED</p>				<p>SCALE <b>NONE</b></p>		<p>RELEASED DATE <b>3/5/13</b></p>		<p>REVISION DATE <b>10/8/13</b></p>		<p>REV. NO. <b>A</b></p>	
<p>REV. NO.</p>		<p>DESCRIPTION/ECO NUMBER</p>		<p>APPV'D DATE</p>										<p>SHEET <b>1</b> OF <b>1</b></p>	